

Note: The red X indicates to remove the white wire from the run capacitor and connect the BROWN wire from STA01 only to the white wire. Connect the STA01 white wire to the empty terminal created when the white wire was removed.

Connect the STA01 orange wire to the red wire side of the run capacitor alongside the red wire.
Do not remove the red wire.

Splice the black wire into the compressor black wire in a convenient location near the relay.

